



# Alfa Romeo

Model	Factory BHP	Factory Torque	Stage 1 HP	Stage 1 Torque	Stage 2 HP	Stage 2 Torque
-------	-------------	----------------	------------	----------------	------------	----------------

## 145 / 146

1.9i JTD 105	105 hp	255 nm	132 hp	300 nm	Ask Us	Ask Us
--------------	--------	--------	--------	--------	--------	--------

Model	Factory BHP	Factory Torque	Stage 1 HP	Stage 1 Torque	Stage 2 HP	Stage 2 Torque
-------	-------------	----------------	------------	----------------	------------	----------------

## 147

147 JTD 1.9 8V 100	100 hp	200 NM	130 hp	260 NM	ask us	ask us
147 JTD 1.9 8V 115	115 hp	275 NM	145 hp	325 NM	ask us	ask us
147 JTD 1.9 MultiJet (JTDM) 120	120 hp	280 NM	145 hp	340 NM	ask us	ask us
147 JTD 1.9 MultiJet (JTDM) 126	126 hp	305 NM	153 hp	365 NM	ask us	ask us
147 JTD 1.9 MultiJet (JTDM) 140	140 hp	305 NM	170 hp	365 NM	180 hp	380 nm
147 JTD 1.9 MultiJet (JTDM) 150	150 hp	305 NM	182 hp	365 NM	190 hp	380 NM
147 JTD 1.9 MultiJet (JTDM) 170	170 hp	330 NM	204 hp	390 NM	ask us	ask us
147 1.6 TS 16V 120	120 hp	146 NM	128 hp	161 NM	ask us	ask us
147 1.6 TS ECO 105	105 hp	140 NM	115 hp	155 NM	ask us	ask us
147 2.0 TS 150	150 hp	181 NM	165 hp	201 NM	ask us	ask us
147 3.2 V6 24V 250	250 hp	300 NM	268 hp	325 NM	ask us	ask us

Model	Factory BHP	Factory Torque	Stage 1 HP	Stage 1 Torque	Stage 2 HP	Stage 2 Torque
-------	-------------	----------------	------------	----------------	------------	----------------

## 156

156 JTD 1.9 105	105 hp	255 NM	140 hp	315 NM	ask us	ask us
156 JTD 1.9 110	110 hp	275 NM	140 hp	330 NM	ask us	ask us
156 JTD 1.9 115	115 hp	275 NM	145 hp	325 NM	ask us	ask us
156 JTD 1.9 MultiJet (JTDM) 140	140 hp	305 NM	170 hp	365 NM	180 hp	380 nm
156 JTD 1.9 MultiJet (JTDM) 150	150 hp	305 NM	182 hp	360 NM	190 hp	380 NM
156 JTD 2.4 136	136 hp	310 NM	168 hp	370 NM	ask us	ask us
156 JTD 2.4 140	140 hp	304 NM	173 hp	382 NM	ask us	ask us
156 JTD 2.4 150	150 hp	304 NM	180 hp	370 NM	ask us	ask us
156 JTD 2.4 MultiJet (JTDM) 175	175 hp	385 NM	205 hp	450 NM	220 hp	470 nm
156 1.8 16V 140	140 hp	163 NM	152 hp	177 NM	ask us	ask us
156 1.8 16V 144	144 hp	169 NM	157 hp	184 NM	ask us	ask us
156 2.0 16V 150	150 hp	181 NM	164 hp	201 NM	ask us	ask us
156 2.0 16V 155	155 hp	187 NM	170 hp	208 NM	ask us	ask us
156 2.5 V6 24V 192	192 hp	218 NM	207 hp	243 NM	ask us	ask us
156 GTA 250	250 hp	300 NM	268 hp	325 NM	ask us	ask us

Model	Factory BHP	Factory Torque	Stage 1 HP	Stage 1 Torque	Stage 2 HP	Stage 2 Torque
-------	-------------	----------------	------------	----------------	------------	----------------

## 159

159 JTD 1.9 MultiJet (JTDM) 120	120 hp	280 NM	152 hp	340 NM	ask us	ask us
159 JTD 1.9 MultiJet (JTDM) 150	150 hp	320 NM	182 hp	375 NM	190 hp	380 nm
159 JTD 1.9 MultiJet (JTDM) 170	170 hp	360 NM	204 hp	420 NM	215 hp	465 nm
159 JTD 2.4 MultiJet (JTDM) 200	200 hp	400 NM	230 hp	460 NM	ask us	ask us
159 JTD 2.4 MultiJet (JTDM) 210	210 hp	400 NM	240 hp	460 NM	ask us	ask us

Model	Factory BHP	Factory Torque	Stage 1 HP	Stage 1 Torque	Stage 2 HP	Stage 2 Torque
-------	-------------	----------------	------------	----------------	------------	----------------

166						
166 2.0 TS 16V	150 hp	182 NM	170 hp	200 NM	ask us	ask us
166 3.0 V6 220	220 hp	265 NM	232 hp	283 NM	ask us	ask us
166 JTD 2.4 10V 150	150 hp	305 NM	180 hp	365 NM	ask us	ask us
166 JTD 2.4 136	136 hp	310 NM	168 hp	370 NM	ask us	ask us
166 JTD 2.4 140	140 hp	304 NM	173 hp	382 NM	ask us	ask us
166 JTD 2.4 150	150 hp	305 NM	175 hp	382 NM	ask us	ask us
166 JTD 2.4 MultiJet (JTDM) 175	175 hp	385 NM	208 hp	445 NM	220 hp	470 nm
166 JTD 2.4 MultiJet (JTDM) 175	175 hp	330 NM	208 hp	380 NM	220 hp	380 nm
166 JTD 2.4 MultiJet (JTDM) 185	185 hp	385 NM	215 hp	450 NM	ask us	ask us

Model	Factory BHP	Factory Torque	Stage 1 HP	Stage 1 Torque	Stage 2 HP	Stage 2 Torque
-------	-------------	----------------	------------	----------------	------------	----------------

Brera/GT/GTV/Spider						
Brera JTD 2.4 MultiJet (JTDM) 200	200 hp	400 NM	230 hp	460 NM	ask us	ask us
Brera JTD 2.4 MultiJet (JTDM) 210	210 hp	400 NM	240 hp	460 NM	ask us	ask us
GT JTD 1.9 MultiJet (JTDM) 150	150 hp	305 NM	182 hp	360 NM	190 hp	380 NM
GT JTD 1.9 MultiJet (JTDM) 170	170 hp	330 NM	204 hp	390 NM	215 hp	465 nm
GTV 2.0 TS 16V 150	150 hp	186 NM	165 hp	206 NM	ask us	ask us
GTV 3.0 V6 218	218 hp	275 NM	245 hp	309 NM	ask us	ask us
Spider JTD 2.4 MultiJet (JTDM) 200	200 hp	400 NM	230 hp	455 NM	ask us	ask us
Spider JTD 2.4 MultiJet (JTDM) 210	210 hp	400 NM	240 hp	460 NM	ask us	ask us

Model	Factory BHP	Factory Torque	Stage 1 HP	Stage 1 Torque	Stage 2 HP	Stage 2 Torque
-------	-------------	----------------	------------	----------------	------------	----------------

MiTo / Giulietta						
MiTo 1.6 JTD m 16v 120	120 hp	320 NM	155 hp	384 NM	ask us	ask us
Giulietta 1.6 JTD m 16v 120	120 hp	320 NM	155 hp	384 NM	ask us	ask us