



# BMW

Model	Factory BHP	Factory Torque	Stage 1 HP	Stage 1 Torque	Stage 2 HP	Stage 2 Torque
-------	-------------	----------------	------------	----------------	------------	----------------

### 1 Series

BMW 116i 115	115 hp	150 nm	127 hp	169 nm	Ask Us	Ask Us
BMW 116i 121	121 hp	160 nm	136 hp	180 nm	Ask Us	Ask Us
BMW 118d 122	122 hp	280 nm	153 hp	330 nm	Ask Us	Ask Us
BMW 118d 143	143 hp	300 nm	178 hp	360 nm	Ask Us	Ask Us
BMW 118i 129	129 hp	180 nm	144 hp	200 nm	Ask Us	Ask Us
BMW 118i 143	143 hp	190 nm	158 hp	210 nm	Ask Us	Ask Us
BMW 120d 163	163 hp	340 nm	193 hp	400 nm	200 hp	410 nm
BMW 120d 177	177 hp	350 nm	208 hp	400nm	215 hp	420 nm
BMW 120i 150	150 hp	200 nm	165 hp	220 nm	Ask Us	Ask Us
BMW 120i 170	170 hp	210 nm	185 hp	230 nm	Ask Us	Ask Us
BMW 123d 204	204 hp	400 nm	239 hp	450 nm	Ask Us	Ask Us
BMW 125i 218	218 hp	270 nm	230 hp	290 nm	Ask Us	Ask Us
BMW 130i 265	265 hp	315 nm	280 hp	335 nm	Ask Us	Ask Us
BMW 135i 306	306 hp	400 nm	351 hp	465 nm	Ask Us	Ask Us

Model	Factory BHP	Factory Torque	Stage 1 HP	Stage 1 Torque	Stage 2 HP	Stage 2 Torque
-------	-------------	----------------	------------	----------------	------------	----------------

### 3 Series E36

BMW 316i 102	102 hp	150 NM	111 hp	168 NM	Ask Us	Ask Us
BMW 318 TDS 90	90 hp	190 NM	113 hp	255 NM	Ask Us	Ask Us
BMW 318 TDS Compact 90	90 hp	190 NM	113 hp	255 NM	Ask Us	Ask Us
BMW 318i 115	115 hp	168 NM	127 hp	187 NM	Ask Us	Ask Us
BMW 318is 140	140 hp	175 NM	151 hp	198 NM	Ask Us	Ask Us
BMW 320i 129	129 hp	164 NM	140 hp	182 NM	Ask Us	Ask Us
BMW 320i 24V 150	150 hp	190 NM	163 hp	212 NM	Ask Us	Ask Us
BMW 323i 170	170 hp	245 NM	182 hp	272 NM	Ask Us	Ask Us
BMW 325 TD 115	115 hp	245 NM	141 hp	288 NM	Ask Us	Ask Us
BMW 325 TDS 143	143 hp	260 NM	175 hp	320 NM	Ask Us	Ask Us
BMW 325i 170	170 hp	222 NM	186 hp	243 NM	Ask Us	Ask Us
BMW 325i 192	192 hp	245 NM	206 hp	280 NM	Ask Us	Ask Us
BMW 328i 193	193 hp	280 NM	211 hp	300 NM	Ask Us	Ask Us
BMW M3 3.0 286	286 hp	320 NM	305 hp	340 NM	Ask Us	Ask Us
BMW M3 3.2i 321	321 hp	350 NM	340 hp	382 NM	Ask Us	Ask Us
BMW M3 3.2i Coupe 321	321 hp	350 NM	340 hp	382 NM	Ask Us	Ask Us

Model	Factory BHP	Factory Torque	Stage 1 HP	Stage 1 Torque	Stage 2 HP	Stage 2 Torque
-------	-------------	----------------	------------	----------------	------------	----------------

### 3 Series E46

BMW 316i 105	105 hp	165 NM	115 hp	183 NM	Ask Us	Ask Us
BMW 316i 115	115 hp	175 NM	127 hp	195 NM	Ask Us	Ask Us
BMW 318ci 143	143 hp	200 NM	158 hp	220 NM	Ask Us	Ask Us
BMW 318ci 150	150 hp	190 NM	163 hp	212 NM	Ask Us	Ask Us
BMW 318d 116 265NM	116 hp	265 NM	146 hp	330 NM	Ask Us	Ask Us
BMW 318d 116 280NM	116 hp	280 NM	148 hp	340 NM	Ask Us	Ask Us
BMW 318i 118	118 hp	180 NM	130 hp	200 NM	Ask Us	Ask Us
BMW 320d 136	136 hp	280 NM	168 hp	348 NM	Ask Us	Ask Us
BMW 320d 150	150 hp	330 NM	175 hp	380 NM	185 hp	400 NM
BMW 320i 150	150 hp	190 NM	163 hp	212 NM	Ask Us	Ask Us
BMW 320i 170	170 hp	210 NM	185 hp	230 NM	Ask Us	Ask Us
BMW 323ci 170	170 hp	245 NM	188 hp	270 NM	Ask Us	Ask Us
BMW 325i 192	192 hp	245 NM	208 hp	270 NM	Ask Us	Ask Us
BMW 328i 193	193 hp	280 NM	204 hp	312 NM	Ask Us	Ask Us
BMW 330d 184	184 hp	390 NM	212 hp	450 NM	Ask Us	Ask Us
BMW 330d 204	204 hp	410 NM	234 hp	470 NM	Ask Us	Ask Us
BMW 330i 231	231 hp	300 NM	246 hp	325 NM	Ask Us	Ask Us
BMW M3 343	343 hp	365 NM	363 hp	395 NM	Ask Us	Ask Us
BMW M3 CSL 360	360 hp	370 NM	385 hp	395 NM	Ask Us	Ask Us
BMW M3 GTR 350	350 hp	365 NM	420 hp	430 NM	Ask Us	Ask Us

Model	Factory BHP	Factory Torque	Stage 1 HP	Stage 1 Torque	Stage 2 HP	Stage 2 Torque
<b>3 Series E90-93</b>						
BMW 316i 122	122 hp	160 NM	134 hp	174 NM	Ask Us	Ask Us
BMW 318d 122	122 hp	280 NM	147 hp	330 NM	Ask Us	Ask Us
BMW 318d 143	143 hp	300 NM	178 hp	360 NM	Ask Us	Ask Us
BMW 318i 129	129 hp	180 NM	141 hp	200 NM	Ask Us	Ask Us
BMW 318i 143	143 hp	190 NM	158 hp	210 NM	Ask Us	Ask Us
BMW 320d 150 (Fleet)	150 hp	330 NM	190 hp	390 NM	Ask Us	Ask Us
BMW 320d 163	163 hp	340 NM	193 hp	400 NM	200 hp	410 nm
BMW 320d 177	177 hp	350 NM	208 hp	410 NM	215 hp	420 nm
BMW 320i 150	150 hp	200 NM	162 hp	225 NM	Ask Us	Ask Us
BMW 320i 170	170 hp	210 NM	185 hp	230 NM	Ask Us	Ask Us
BMW 320si 173	173 hp	200 NM	188 hp	218 NM	Ask Us	Ask Us
BMW 323i 177	177 hp	230 NM	189 hp	250 NM	Ask Us	Ask Us
BMW 325d 197	197 hp	400 NM	227 hp	455 NM	Ask Us	Ask Us
BMW 325i 218	218 hp	250 NM	233 hp	278 NM	Ask Us	Ask Us
BMW 328i 231	231 hp	270 NM	250 hp	290 NM	Ask Us	Ask Us
BMW 330d 231	231 hp	500 NM	267 hp	560 NM	Ask Us	Ask Us
BMW 330d 245	245 hp	520 NM	282 hp	280 NM	Ask Us	Ask Us
BMW 330i 258	258 hp	300 NM	278 hp	325 NM	Ask Us	Ask Us
BMW 330i 272	272 hp	320 NM	287 hp	340 NM	Ask Us	Ask Us
BMW 335d 286	286 hp	580 NM	313 hp	630 NM	340 hp	700 nm
BMW 335i 306	306 hp	400 NM	351 hp	465 NM	Ask Us	Ask Us
BMW M3 420	420 hp	400 NM	445 hp	428 NM	Ask Us	Ask Us

Model	Factory BHP	Factory Torque	Stage 1 HP	Stage 1 Torque	Stage 2 HP	Stage 2 Torque
<b>5 Series E39</b>						
BMW 5er 520d 136	136 hp	280 NM	168 hp	348 NM	Ask Us	Ask Us
BMW 5er 520i 170	170 hp	210 NM	185 hp	230 NM	Ask Us	Ask Us
BMW 5er 523i 170	170 hp	245 NM	187 hp	272 NM	Ask Us	Ask Us
BMW 5er 525 TDS 143	143 hp	280 NM	172 hp	350 NM	Ask Us	Ask Us
BMW 5er 525d 163	163 hp	350 NM	191 hp	410 NM	Ask Us	Ask Us
BMW 5er 525i 192	192 hp	245 NM	208 hp	270 NM	Ask Us	Ask Us
BMW 5er 528i 193	193 hp	280 NM	204 hp	312 NM	Ask Us	Ask Us
BMW 5er 530d 184	184 hp	390 NM	212 hp	450 NM	Ask Us	Ask Us
BMW 5er 530d 193	193 hp	410 NM	221 hp	480 NM	Ask Us	Ask Us
BMW 5er 530i 231	231 hp	300 NM	246 hp	325 NM	Ask Us	Ask Us
BMW 5er 535i 245	245 hp	345 NM	260 hp	370 NM	Ask Us	Ask Us
BMW 5er 540i 286	286 hp	440 NM	308 hp	470 NM	Ask Us	Ask Us
BMW 5er M5 5.0 400	400 hp	500 NM	420 hp	525 NM	Ask Us	Ask Us

Model	Factory BHP	Factory Torque	Stage 1 HP	Stage 1 Torque	Stage 2 HP	Stage 2 Torque
<b>5 Series E60</b>						
BMW 520d 163	163 hp	340 NM	193 hp	400 NM	200 hp	410 nm
BMW 520d 177	177 hp	350 NM	208 hp	410 NM	215 hp	420 nm
BMW 520i 170	170 hp	210 NM	182 hp	230 NM	Ask Us	Ask Us
BMW 523i 177	177 hp	230 NM	189 hp	250 NM	Ask Us	Ask Us
BMW 523i 190	190 hp	240 NM	205 hp	260 NM	Ask Us	Ask Us
BMW 525d 177	177 hp	400 NM	207 hp	460 NM	Ask Us	Ask Us
BMW 525d 197	197 hp	400 NM	227 hp	455 NM	Ask Us	Ask Us
BMW 525i 192	192 hp	245 NM	211 hp	265 NM	Ask Us	Ask Us
BMW 525i 218	218 hp	250 NM	233 hp	278 NM	Ask Us	Ask Us
BMW 530d 218	218 hp	500 NM	248 hp	560 NM	Ask Us	Ask Us
BMW 530d 231	231 hp	500 NM	261 hp	560 NM	Ask Us	Ask Us
BMW 530d 235	235 hp	500 NM	265 hp	560 NM	Ask Us	Ask Us
BMW 530i 258	258 hp	300 NM	270 hp	320 NM	Ask Us	Ask Us

BMW 530i 272	272 hp	320 NM	287 hp	340 NM	Ask Us	Ask Us
BMW 535d 272	272 hp	560 NM	313 hp	630 NM	340 hp	700 nm
BMW 535d 286	286 hp	580 NM	313 hp	630 NM	340 hp	700 nm
BMW 540i 306	306 hp	390 NM	336 hp	430 NM	Ask Us	Ask Us
BMW 545i 333	333 hp	450 NM	353 hp	475 NM	Ask Us	Ask Us
BMW 550i 367	367 hp	490 NM	387 hp	520 NM	Ask Us	Ask Us
BMW M5 507	507 hp	520 NM	535 hp	550 NM	Ask Us	Ask Us

Model	Factory BHP	Factory Torque	Stage 1 HP	Stage 1 Torque	Stage 2 HP	Stage 2 Torque
-------	-------------	----------------	------------	----------------	------------	----------------

**6 Series E63**

BMW 630i 258	258 hp	300 NM	278 hp	325 NM	Ask Us	Ask Us
BMW 630i 272	272 hp	NM	287 hp	340 NM	Ask Us	Ask Us
BMW 635d 286	286 hp	580 NM	316 hp	635 NM	340 hp	700 nm
BMW 645CI 333	333 hp	NM	353 hp	475 NM	Ask Us	Ask Us
BMW 650CI 367	367 hp	490 NM	387 hp	520 NM	Ask Us	Ask Us
BMW M6 507	507 hp	520 NM	535 hp	550 NM	Ask Us	Ask Us

Model	Factory BHP	Factory Torque	Stage 1 HP	Stage 1 Torque	Stage 2 HP	Stage 2 Torque
-------	-------------	----------------	------------	----------------	------------	----------------

**7 Series E65**

BMW 730d 218	218 hp	500 NM	248 hp	565 NM	Ask Us	Ask Us
BMW 730d 231	231 hp	520 NM	261 hp	570 NM	Ask Us	Ask Us
BMW 730i 23	231 hp	300 NM	254 hp	318 NM	Ask Us	Ask Us
BMW 730i 258	258 hp	300 NM	278 hp	325 NM	Ask Us	Ask Us
BMW 735i 272	272 hp	360 NM	300 hp	385 NM	Ask Us	Ask Us
BMW 740d 259	259 hp	600 NM	289 hp	660 NM	Ask Us	Ask Us
BMW 740i 306	306 hp	390 NM	336 hp	430 NM	Ask Us	Ask Us
BMW 745d 330	330 hp	750 NM	375 hp	840 NM	Ask Us	Ask Us
BMW 745i 333	333 hp	450 NM	366 hp	460 NM	Ask Us	Ask Us
BMW 750i 367	367 hp	490 NM	382 hp	515 NM	Ask Us	Ask Us
BMW 760i 445	445 hp	600 NM	489 hp	640 NM	Ask Us	Ask Us

Model	Factory BHP	Factory Torque	Stage 1 HP	Stage 1 Torque	Stage 2 HP	Stage 2 Torque
-------	-------------	----------------	------------	----------------	------------	----------------

**Z Series**

BMW Coupe Z3 2.8 193	193 hp	280 NM	211 hp	310 NM	Ask Us	Ask Us
BMW Coupe Z3 3.0 231	231 hp	300 NM	246 hp	325 NM	Ask Us	Ask Us
BMW Z3 Roadster 1.8 115	115 hp	168 NM	127 hp	185 NM	Ask Us	Ask Us
BMW Z3 Roadster 1.9 118	118 hp	180 NM	129 hp	196 NM	Ask Us	Ask Us
BMW Z3 Roadster 2.0 150	150 hp	190 NM	166 hp	210 NM	Ask Us	Ask Us
BMW Z3 Roadster 2.8 193	193 hp	280 NM	204 hp	310 NM	Ask Us	Ask Us
BMW Z3 Roadster 3.0 231	231 hp	300 NM	246 hp	325 NM	Ask Us	Ask Us
BMW Z3 Roadster 3.2 M3 321	321 hp	350 NM	339 hp	380 NM	Ask Us	Ask Us
BMW Z4 Roadster 2.0i 150	150 hp	200 NM	162 hp	225 NM	Ask Us	Ask Us
BMW Z4 Roadster 2.2i 170	170 hp	210 NM	185 hp	235 NM	Ask Us	Ask Us
BMW Z4 Roadster 2.5i 177	177 hp	230 NM	192 hp	250 NM	Ask Us	Ask Us
BMW Z4 Roadster 2.5i 192	192 hp	245 NM	210 hp	265 NM	Ask Us	Ask Us
BMW Z4 Roadster 2.5si 218	218 hp	250 NM	235 hp	270 NM	Ask Us	Ask Us
BMW Z4 Roadster 3.0i 231	231 hp	300 NM	251 hp	330 NM	Ask Us	Ask Us
BMW Z4 Roadster 3.0si 265	265 hp	315 NM	287 hp	345 NM	Ask Us	Ask Us
BMW Z4 Roadster M 343	343 hp	365 NM	363 hp	395 NM	Ask Us	Ask Us
BMW Z8 Roadster 5.0i 400	400 hp	500 NM	420 hp	525 NM	Ask Us	Ask Us

Model	Factory BHP	Factory Torque	Stage 1 HP	Stage 1 Torque	Stage 2 HP	Stage 2 Torque
-------	-------------	----------------	------------	----------------	------------	----------------

<b>X3 E83 F25</b>						
BMW X3 2.0d 150	150 hp	330 NM	175 hp	380 nm	185 hp	400 nm
BMW X3 2.0d 177	177 hp	350 NM	208 hp	410 NM	215 hp	420 nm
BMW X3 2.0i 150	150 hp	200 NM	168 hp	220 NM	Ask Us	Ask Us
BMW X3 2.5i 192	192 hp	245 NM	211 hp	257 NM	Ask Us	Ask Us
BMW X3 2.5si 218	218 hp	250 NM	233 hp	278 NM	Ask Us	Ask Us
BMW X3 3.0d 204	204 hp	410 NM	234 hp	470 NM	Ask Us	Ask Us
BMW X3 3.0d 218	218 hp	500 NM	248 hp	565 NM	Ask Us	Ask Us
BMW X3 3.0i 231	231 hp	300 NM	254 hp	330 NM	Ask Us	Ask Us
BMW X3 3.0sd 286	286 hp	580 NM	316 hp	635 NM	340 hp	700 nm
BMW X3 3.0si 272	272 hp	315 NM	287 hp	344 NM	Ask Us	Ask Us

Model	Factory BHP	Factory Torque	Stage 1 HP	Stage 1 Torque	Stage 2 HP	Stage 2 Torque
-------	-------------	----------------	------------	----------------	------------	----------------

<b>X5 E53</b>						
BMW X5 3.0d 184	184 hp	410 NM	214 hp	490 NM	Ask Us	Ask Us
BMW X5 3.0d 218	218 hp	500 NM	248 hp	565 NM	Ask Us	Ask Us
BMW X5 3.0d 235	235 hp	520 NM	265 hp	580 NM	Ask Us	Ask Us
BMW X5 3.0i 231	231 hp	300 NM	246 hp	325 NM	Ask Us	Ask Us
BMW X5 3.0sd 286	286 hp	580 NM	316 hp	635 NM	340 hp	700 nm
BMW X5 3.0si 272	272 hp	315 NM	287 hp	345 NM	Ask Us	Ask Us
BMW X5 4.4i 286	286 hp	440 NM	305 hp	475 NM	Ask Us	Ask Us
BMW X5 4.4i 320	320 hp	440 NM	335 hp	465 NM	Ask Us	Ask Us
BMW X5 4.6is 347	347 hp	480 NM	360 hp	515 NM	Ask Us	Ask Us
BMW X5 4.8i 355	355 hp	475 NM	390 hp	515 NM	Ask Us	Ask Us
BMW X5 4.8is 360	360 hp	500 NM	396 hp	540 NM	Ask Us	Ask Us

Model	Factory BHP	Factory Torque	Stage 1 HP	Stage 1 Torque	Stage 2 HP	Stage 2 Torque
-------	-------------	----------------	------------	----------------	------------	----------------

<b>X5 E53</b>						
BMW X6 xDrive 30d 235	235 hp	520 NM	270 hp	585 NM	Ask Us	Ask Us
BMW X6 xDrive 35d 286	286 hp	580 NM	324 hp	650 NM	340 hp	700 nm
BMW X6 xDrive 35i 306	306 hp	400 NM	Ask us	Ask us	Ask Us	Ask Us
BMW X6 xDrive 50i 407	408 hp	600 NM	Ask us	Ask us	Ask Us	Ask Us